

Hepa Filter Housing Installation

- Clipper Vac® Tote® -

- Step 1** Remove the existing exhaust cover plate (six screws).
- Step 2** Position the Hepa filter housing with the vent slots facing down, and align the screw holes.
- Step 3** Start all screws before tightening any.
- Step 4** Seal the sides where the housing contacts the main body of the machine with a small bead of silicone.

