

Clipper Vac® Attachment Compatible with Oster® A6



Step 1 Remove the blade from your clipper to have an open view of the upper housing.

Step 2 Clean both the top of the clipper and the Clipper Vac® Attachment with alcohol to remove any residual oils. Remove the drive cover (2 small screws on underside of clipper). Open the small tube of silicone supplied with attachment and apply a small 1/4" spot of silicone on the clipper housing (**PHOTO A**).



Step 3 Re-install drive cover and screws. This will help to sturdy the drive over while allowing it to be removed for service. Then place a liberal amount of silicone on the entire bottom of the black attachment (**PHOTO B**).

Step 4 Place the Clipper Vac® Attachment, silicone side down, on the top of your clipper making sure to align the front edge of the attachment with edge of clipper. Press firmly to secure.

Step 5 Excess silicone should squeeze from under the attachment. Trim with a razor blade or other sharp object after it dries.

Note: Allow 24 hours before using the clipper to insure a proper seal on the clipper.

M.D.C. Romani, Inc./Clipper Vac® is not affiliated with, authorized by or endorsed in any way by Oster®.