

Wing Nut Filter Change Procedure

- Clipper Vac® Units -



Note When ordering filters, be sure to specify if your filter is held in place by a wing nut or rubber band.

Step 1 Locate the wing nut on the bottom of the filter.

Step 2 Remove the nut.

Step 3 Pull the filter downward and remove.

Step 4 Clean area where filter contacts the motor.

Step 5 Install the new filter and replace the nut.

Step 6 Tighten the nut.