

# Hose Replacement Procedure

## - Clipper Vac® Units -

### You Will Need

- 3/4x10 Clipper Vac® Hose (Tote®, Mini®)
- 3/4x12 Clipper Vac® Hose (B&B® 1 / 2 Operator, Model 1 / 1A®)
- Swivel Adapter (Tote®, Mini®, B&B® 1 / 2 Operator, Model 1/1A®)
- Hose Adapter (Tote®, Mini®, Model 1 / 1A®)

- Step 1**      Stretch the Clipper Vac® hose gently to reduce the coiling from being packaged.
- Step 2**      The Swivel Adapter goes into the end of the hose and connects the hose to the Clipper Attachment (the piece that goes onto your clipper). The Swivel Adapter can be removed from an existing hose by directly pulling it out. When installing a new/existing Swivel Adapter into a new/existing hose, wipe a small amount of concentrated dish soap or shampoo onto the end of it a lubricant. This will help the swivel adapter to slide into the hose easier.
- Step 3**      The piece that connects the hose to the machine is called the Unit Hose Adapter. It is removed by twisting it counter clockwise. When reinstalling it, simply thread it clockwise onto the end of the Clipper Vac® hose with the words “M.D.C. Romani, Inc.” facing towards the unit. The inside threading of the Adapter will grip the hose. Tighten until snug.
- Step 4**      Once the hose is completely assembled, test it on your Clipper Vac®.

**Note:**      *IF THE HOSE IS NOISY (SQUEALING/WHISTLING) you will need to reverse the end adapters. To do this, remove the Swivel Adapter and place it in the opposite hose end then remove the Hose Adapter and place it in the opposite hose end. Reversing the flow of air through the hose corrects this problem. Often the hose runs quieter in one direct than it does the other.*

**Note:**      *Reversing your Clipper Vac® hose ends from time to time will allow for more even wear throughout the hose.*