

Clipper Vac® Attachment Compatible with Wahl® KM2



- Step 1** Turn your current clipper upside down and remove the four (4) visible screws.
- Step 1** Remember where the screws belong (length of screws) as you will need to replace these.
- Step 1** Remove the top housing of the clipper.
- Step 1** Place the new top housing with the Clipper Vac® Attachment on the clipper and replace the screws.

Note: *DO NOT OVER-TIGHTEN THE SCREWS! Doing so risks stripping the inside of the clipper.*

M.D.C. Romani, Inc./Clipper Vac® is not affiliated with, authorized by or endorsed in any way by Wahl®.