

# Door Gasket Procedure

## - Clipper Vac® Units -



### You Will Need

- Mineral Spirits or Rubbing Alcohol or Hair Dryer
- Silicone

**Step 1** Remove the old gasket. Clean the area with mineral spirits, rubbing alcohol, or heat it with a human hair dryer and rub it off.

**Step 2** Position your new gasket on your door **BEFORE** removing the tape, aligning all four (4) corners.

**Step 3** Pull the tape in small increments (we recommend 1/2" - 3/4") at a time and position the gasket along the edge without going over it.

**Step 4** Use silicone to seal corners and fill gaps—allow to dry.

**Note:** *Please be patient while applying gasket to the door as you can **NOT** remove it once the adhesive comes into contact with the door.*